

Care and maintenance

Tips for cutting @claryl picture framing glass

- ▶ Always wear gloves to prevent fingers from being squashed or cut.
- ▶ Put a photo mount between the glass and the rear of the glass cutter. This will prevent scratches.
- ▶ Regularly brush the glass cutter clean with a brush, so that no splinters are left behind.

Tips for cleaning @claryl picture framing glass

- ▶ Put the glass on a clean, non-abrasive surface.
- ▶ Use a clean, lint-free cotton or paper cloth, that does not contain any lotion and does not scratch. A microfibre cloth is also possible, if it is washed daily.
- ▶ Stains or deposits can best be removed using a mixture of 75% softened water and 25% methylated spirit. Of course, you can also use a glass cleaning compound, but not all cleaners are suitable for this (often labelled as glazing agents). If the product contains silicones, alkaline or fluorine, it increases the reflectance of the glass.
- ▶ Clean the glass applying rotary movements to prevent streaking.
- ▶ If it is very dirty we advise first cleaning the glass with lukewarm water with a small amount of normal washing up detergent. Rinse the glass afterwards with water and dry it with a clean paper or cotton cloth. Then wait 5 to 10 minutes before starting to frame a picture. Then you will know for sure that the glass has completely dried.